

---

---

## Single-Switch Single-Appliance Unit #1490

---

---

### USER'S GUIDE



**For Technical Support:**

Call our Technical Service Department  
Monday through Friday, 9 a.m. to 5 p.m. (EST)  
1-800-832-8697  
[customer\\_support@enablingdevices.com](mailto:customer_support@enablingdevices.com)



50 Broadway  
Hawthorne, NY 10532  
Tel. 914.747.3070 / Fax 914.747.3480  
Toll Free 800.832.8697  
[www.enablingdevices.com](http://www.enablingdevices.com)

### Latch or Momentary!

This remote operates most AC appliances from a distance of up to 20 feet. Simply plug the appliance into the receiver and activate the remote transmitter with a capability switch. Choose either latch or momentary activation. With the latch selection, the appliance will run until the user turns it off by activating the switch again. In the momentary mode, the appliance will activate only when a switch is pressed and will shut off when switch is released. (117 VAC output maximum 600 watts). Size: 7"L x 4"W x 2"H. Requires Capability Switch and 2 AA Batteries. Weight: ¾ lbs.

### Installation and operating instructions:

1. Set the frequency code on the white receiver to the letter "A", which is located on the front of the unit.
2. Insert two "AA" alkaline batteries in the transmitter's battery compartment. Use alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types together.
3. Plug your capability switch into the jack on the transmitter.
4. Check that the power switch on your appliance is "On", and plug the appliance into the receiver module.
5. Plug the receiver module into any (unswitched) AC wall outlet and **raise the antenna**. (Note: the range of the remote module can be decreased by simply lowering the antenna.)
6. Activate the remote transmitter unit using your capability switch.

### Mode Settings:

**Momentary Mode:** Turn the selector switch to the "Momentary" position. Device will turn on with sustained activation of your switch. Once the switch is released, the device will immediately turn off.

**Latch Mode:** Turn the selector switch to the "Latch" position. Device will turn on with first switch activation and remain on until turned off by a second switch activation.

**Please Note:** these operations will be accompanied by a small audible "click" produced from the receiver module. This is normal

### Troubleshooting:

**Problem:** The receiver module doesn't "click" when the switch on the transmitter module is activated.

**Action #1:** Check the frequencies of both modules to make sure they are set the same.

**Action #2:** Replace the batteries in the transmitter module.

**Action # 3:** Raise the antenna on receiver to fully extended length.

**Problem:** The appliance doesn't turn on when the switch on the transmitter module is activated.

**Action #1:** Check to see if the appliance's power switch is set to the "On" position.

**Action #2:** Check the frequencies of both modules to make sure they are set the same.

### Care of Unit:

The Single-Switch Single-Appliance Unit can be wiped clean with any household multi-purpose cleaner and disinfectant. We recommend Simple Green, which is a non toxic biodegradable all-purpose cleaner.

**Do not submerge** the unit, as it will damage the contents and the electrical components.

**Do not use abrasive cleaners,** as they will scratch the surface of the unit.